



		_			_ 14		
	<b>PR©TECH</b> <sup>®</sup>						
	703001 - 2 STAGE INDUCER KIT INSTALLATION INSTRUCTIONS						
	Kit includes 1) Inducer, 2) Pressure Switch Hose, 3) Mounting Plate for 14" Upflows, 4) Instructions						
	RECOMMENDED PRESSU			DOWNFLOW APPLICATIONS			
	Jacket Width "A" Tridelta		"A" MPL	Jacket Width "A" Tridelta "A"		"A" MPL	4
	14" 17 1/2"	7.0* 5.5*	8.5° 6.5°	14" 17 1/2"	7.0" 5.5"	8.5" 6.5"	
	21" 24 1/2"	6.5" 8.5"	8.0" 10.0"	21" 24 1/2"	6.5" 8.5"	8.0" 10.0"	
	Mounting Plate	d Drill 7/32" meter hole.					
			Rotate pressure switch 90 deg. and mount to top plate with	<			
	" A "		nounting plate as shown.	Tridelta	OR PS M	DI	
	1	* US 4' Jacket Widt	h	2	14" Jacket Width		
	Upflo	w Installations Horizontal Appl	Only	Downflow Installations Only Not for Horizontal Applications			
	14" Upflow Installat 14" Downflow Insta 14" Horizontal Insta	Ilation Drill ho	ole per diagram ab	ove.	h Assy. If not airea	dv installed.	1
	703001 IS ONLY F Replacing the follor 70-24319-01, 70-24		ES	_			
	INSTALLATION P 1) Disconnect 120	ROCEDURE FO					
	<ol> <li>2) Turn off gas supply to furnace.</li> <li>3) Remove the two (2) 120 volt power supply flag clips from the induced draft motor power terminals.</li> <li>4) Remove the vent pipe from the draft inducer outlet.</li> <li>5) Remove the pressure switch sensing hose from the inducer.</li> <li>6) Remove the four (4) inducer mounting screws and retain them for installation of replacement inducer.</li> </ol>						
	7) Remove the dra 8) Remove any orig				panel.		
	9) Using the origina 10) Place the vent		-	the replacement	inducer to the fron	t panel.	
	11) Predrill, through 12) Secure the ven					predrilled holes.	
	<ol> <li>Reattach the two (2) power supply wires to the motor terminals.</li> <li>Using the new pressure switch hose, reconnect pressure switch to fitting on the induced draft h</li> </ol>						
 <ul><li>15) Restore primary power supply and gas supply to the furnace.</li><li>16) Test fire the furnace.</li></ul>							
	Caution must be used when installing this part. If instructions are not understood, contact your local distribu 92-26177-517-00						
		<u> </u>	Origi	nal Release N	0.	Pg.	Rev.
Dr. By.	Dat	C	Ongi		••		1.001.