

Installation Instructions

Subbase ASBC01A

For Use With BAC / ABC and BHC / HBC Series Air Handlers

SAFETY CONSIDERATIONS

Installation of this accessory can be hazardous due to electrical components and equipment location (such as a ceiling or elevated structure). Only trained, qualified installers and service mechanics should install and service this equipment.

When installing this accessory, observe precautions in the literature, labels attached to the equipment, and any other safety precautions that apply.

- Follow all safety codes.
- Wear safety glasses and work gloves.
- Use care in handling and installing this accessory.



ELECTRIC SHOCK HAZARD

To avoid the possibility of electrical shock, open and tag all disconnects before performing maintenance on this equipment.

INTRODUCTION

The subbase accessory (Figure 1) provides a stable, raised platform for 6 to 20 ton packaged air handling units. The accessory is recommended for all vertical installations to enable condensate trap construction. See Table 1 for usage by unit size.

Table 1 - Accessory Usage

Unit Sizes	Accessory Kit Part No.
6 to 20 Tons	ASBC01A (Unpainted)

Figure 1 - Subbase (2 supplied per kit)





Figure 2 - Subbase Installation



INSTALLATION

Refer to Figure 2 while performing the following steps:

1. Raise and support one end of the unit higher than the subbase leg height of 6 inches (152 mm).
2. Remove the 2 screws from each of the 2 raised bottom corners of the unit.
3. Place a subbase leg in position on the raised end of the unit. Align the leg mounting holes with the holes in the unit base.
4. Using the screws removed in Step 1, fasten the leg to the bottom of the unit. Tighten all screws and lower the unit onto the subbase leg.
5. Repeat Steps 1-4 for the second leg on the opposite side of the unit.
6. Install the unit according to the base unit Installation instructions.